

Ederhof Microphones Grossmannstrasse 213 D-20539 Hamburg Germany

support@angle.hamburg



Quick Start Guide Kurzanleitung EA5-USB-O



Plug the Angle into a free USB-Port of your computer. You can use the Angle's internal headphone amplifier by plugging Headphones with a 3.5mm stereo Jack into the plug at the Angle's body. Active loudspeakers could also be used.

The Angle is recognized by your computer as "USB audio CODEC". Adjust the settings to use the microphone and optionally speaker.

Schließen Sie das Angle an einen freien USB-Anschluss Ihres Rechners an. An der 3,5mm Klinkenbuchse des Angle können ein Kopfhörer oder aktive Lautsprecher angeschlossen werden.

Das Angle wird vom Rechner als "USB audio CODEC" angezeigt. Passen sie Ihre Audio-Einstellungen so an, dass Mikrofon und optional Lautsprecher entsprechend verwendet werden.